

VPXT6

VISUAL PERFORMANCE[®] EXTREME INSTALLATION QUICKSTART GUIDE

1. Connect speaker wires to spring terminals.
2. Double check that the positive wire (+) is connected to the positive connector (+) and the negative wire (-) is connected to the negative connector (-).
3. Insert speaker into the hole.
4. Tighten Roto-Lock[®] screws using low-torque setting on your screw gun. **NEVER OVER TIGHTEN.**
5. Attach grille.

Note: Please see manual for grille painting instructions at www.sonance.com.



VPXT6 CUT-OUT TEMPLATE

1. Perform an obstruction survey to be certain that there are no joists, conduit, pipes, heating ducts, high-voltage electrical wires, gas lines, pocket doors, or air returns in the walls or ceiling cavities that will interfere with the speaker.
2. Position this cut-out template at the speaker location, then pencil an outline on the ceiling.
3. Cut the mounting hole using a keyhole or drywall saw.
4. Proceed with installation.

NOTE: Please see the manual for detailed instructions at www.sonance.com

